

BASKETBALL


NOTE: Ensure that the **BASKETBALL** keypad insert is inserted into the keypad and that the unit is in **BASKETBALL** mode. See "CHANGING GAME MODES" on page 4 for more information.

- To increase the *HOME* score by 1, press the **HOME SCORE** key.
- To increase the *GUEST* score by 1, press the **GUEST SCORE** key.
- To decrease the *HOME* score by 1, press the **-1 HOME** key.
- To decrease the *GUEST* score by 1, press the **-1 GUEST** key.
- To increase the *PERIOD*, press the **PERIOD** key.
- To indicate a Home *BONUS*, press the **HOME BONUS** key.
- To indicate a Guest *BONUS*, press the **GUEST BONUS** key.
- To clear both the Home and Guest *BONUS* displays, press the **BONUS CLEAR** key.
- To change the *POSSESSION* arrow from the Home team to the Guest team or vice versa, press the **POSS. CHANGE** key.
- To sound the *HORN* at any time, press the **HORN** key located at the top of the keypad.
- To reset the scoreboard for a new game, press and hold the **NEW GAME** key for three seconds.

NOTE: In **BASKETBALL** mode, the LED-4 has a function that makes the scores displayed on the back of the unit parallel with the scores displayed on the front of the unit. The *HOME* score on the back will be displayed as the *GUEST* score on the front and the *GUEST* score on the back will be displayed as the *HOME* score on the front. The *HOME* and *GUEST BONUS* indicators and *POSSESSION* arrows will also trade places. All of the keypad functions remain the same.

To flip-flop the scores, bonus dots, and possession arrows:
Press the **RESET** key quickly followed by the **POSS. CHANGE** key.
To return the unit to normal display mode:
Press the **RESET** key quickly followed by the **POSS. CHANGE** key.

KEY FUNCTIONS



1. **HORN**
Press this key while in any game mode to manually sound the horn.
2. **NEW GAME**
Press and hold this key for three seconds to reset the scoreboard for a new game.
3. **SELECT GAME**
Press and hold this key for three seconds to select a different game to score. See **CHANGING GAME MODES** below for more information.
4. **SET CLOCK**
Press and hold this key for three seconds to set the game clock. See **CLOCK OPERATION** on page 4 for more information.
5. **- 1 MINUTE**
With the game clock stopped, press this key to subtract one minute from the clock.
6. **- 1 SECOND**
With the game clock stopped, press this key to subtract one second from the clock.
7. **- 1 HOME**
Press this key to subtract one from the HOME score.
8. **- 1 GUEST**
Press this key to subtract one from the GUEST score.
9. **KEYPAD INSERT**
There are six keypad inserts:

GAME CODES	BASKETBALL	VOLLEYBALL
WRESTLING	TRACK	TIMED WORKOUT